### **CLASSROOM PODIUM QUICK START**




### TURN IT ON

To turn on the projector, press the PROJ ON button. To playback audio, press the AUDIO ON button. To conserve energy, the DVD/VCR and doc cam only receive power when projector is on.

2

## SELECT DEVICE

Press the button for the device you wish to display on the screen.



3

# SHUT IT DOWN

To shut down, press the OFF button. To conserve energy, please remember to also shut down the Computer when finished.



### GET HELP

For detailed instructions about equipment in this room, visit: <a href="www.plu.edu/itech/classrooms">www.plu.edu/itech/classrooms</a>
To report a problem, visit: <a href="helpdesk.plu.edu">helpdesk.plu.edu</a>
Call Instructional Technologies: 253-535-7509